

GRX USB Software Update Procedure

The GRX update procedure consists of these steps:

1. Download the update file and save it to a USB stick.
2. Start the GRX in recovery mode.
3. Insert the USB stick in the GRX.
4. Start the update procedure.
5. Remove the USB stick
6. Reboot the GRX.

Download the update file.

The update file is named "grx_mx6-ota-relNN.zip". NN is the release number.

Save the update file on a USB stick. The USB stick should be FAT32 formatted.

Start GRX in recovery mode

Turn the GRX completely off. Insert a battery newly charged battery.

Enter recovery mode:

- Pull the TRIGGER button and keep it pulled.
- Turn the GRX on by pressing the POWER button.
- After a second the GRX sound the usual short beep.
- After a few seconds the GRX will sound three longer beeps.
- Push the POWER button once and the GRX will sound a single very long beep.
- Release the trigger button.

The GRX now starts in recovery mode.

Update procedure

In recovery mode you navigate using the POWER button (moves the selection bar) and select a command by pulling the TRIGGER.

Select the command "update from USB drive" and insert the USB stick.

Verify that you want to update wait a few minutes until the red text at the bottom of the screen tells you to select "Reboot system now".

Remove the USB stick and select "Reboot system now".

The POWER button moves the menu bar and the TRIGGER button selects.

Navigate the menu bar to "Reboot system now" by pushing the power button and pull the TRIGGER button.

The GRX software is now updated. The first boot after an update takes a while longer.

---ooOoo---

