



## LTL-X Mark II, Mounting the wet night rails for rain measurements

In order to move the measurement field outside the horizontal base cover during continuous wet measurements, as shown on the figure (see pg. 13 in user manual) the two wet night rails should be mounted.



You will find two wet night rails in the carrying case. Be aware of that there is a left and a right one.



Bushing for the wet night rail

Mount the wet night rails by inserting the rails into the bushing underneath the LTL-X Mark II





Fasten the wet night rails in the rear plate with the screws delivered (M6\*16 mm) with the rails. Make sure that the LTL-X Mark II is resting on the rails before lightening the screws.



The wet night rails are now ready for use. After use dismount the wet night rails by reversing above operations.